



PROJECTOR USER GUIDE

A remote and projector cable kit can be borrowed at the reference desk. There are also laptops available to borrow.



STEP 1.

Turn on the projector using the remote. Batteries for the remote are available at the reference desk.

STEP 2.

Locate the display port panel on the wall. Plug one end of a display cable into the appropriate port, and the other end of the cable into your laptop.



HDMI



VGA



REMINDER

When done, please:

- 1) Unplug your laptop.
- 2) Turn off the projector by pressing the Standby button on the remote.
- 3) Neatly resecure cables.
- 4) Return projector kit and laptop (if borrowed).

Note: Most modern laptops will use the HDMI cable to connect. If your laptop does not have an HDMI port, there are several adaptors included in the kit that fit various ports.

If using the older style VGA cable, you will need to also plug an audio cable into the audio jack to project sound. There is a dual VGA/audio cable included in the kit.

STEP 3.

If you don't see your screen projected on the whiteboard, try changing the projector display with the remote.

The source for HDMI is:
HDMI1

The source for VGA is:
COMP1